




Pickup Switching

Tone Knob in	Tone Knob out
Position 1 Bridge Humbucker	Bridge Coil Split (inner coil on)
Position 2 Bridge + Neck	Bridge + Neck Split (inner coils on)
Position 3 Neck Humbucker	Neck Split (inner coil on)